



INSTALLER REGISTRATION



INSTALLER REGISTRATION

Go to link – www.energymanager.com

Installer Center Login

Username

Password

Remember me

Login

[Forgot your password?](#) >

[Registration](#) >

[Access to EnergyManager Portal](#) >

www.solarwatt.de >

Click on registration and choose “Installer” and hit “Next”

Registration

Which type of user should be created?

User

Installer

[Back](#)

[Next](#)

Choose an username and password, when completed click on “Next”

Register new installer

* These fields must be filled in.

Personal Data

Step 1 of 4

Username *

eMail *

Confirm eMail *

Password *

Confirm Password *

A secure password should contain:

- ✘ upper case letters
- ✘ lower case letters
- ✘ numbers or special characters
- ✘ minimum 8 characters

[Back](#)

[Next](#)

Fill in all required details and click on “Next”

Register new installer

* These fields must be filled in.

Address

Step 2 of 4

Given Name *

Family Name *

Postal Code *

City

Country *

[Back](#)

[Next](#)

Fill in all required details and click on “Next”

Register new installer

* These fields must be filled in.

Commercial Data

Step 3 of 4

eMail *

Phone


Company Name

Main Profession

Postal Code

City

Country *

Accessibility 

[Back](#)

[Next](#)

Accept the terms and click “Submit”

Register new installer

* These fields must be filled in.

Terms

Step 4 of 4

Nutzungsbedingungen
des Energy Portals der SOLARWATT GmbH

1. Geltungsbereich, Änderungsbefugnis, Vertragsinhalt, Wechsel des Vertragspartners
1.1 Die nachstehenden Nutzungsbedingungen (ANB) gelten für alle Rechtsgeschäfte und die in den Leistungsbeschreibungen angegebenen Leistungen der SOLARWATT GmbH, Maria-Reiche-Straße 2 a in 01109 Dresden, nachfolgend „SOLARWATT“ genannt, mit den Vertragspartnern „nachstehend „Kunde“ genannt für das

I have read and accepted the terms.

I'm not a robot



reCAPTCHA
Privacy - Terms

[Back](#)

Submit

INSTALLER REGISTRATION

Go to link – www.energymanager.com and click on Installer Login

Installer Center Login

 Remember me

[Forgot your password?](#)
[Registration](#)
[Access to EnergyManager Portal](#)
www.solarwatt.de

Once logged in, click on “ Add customer ” to bind the customer to your account.

☰ **INSTALLER CENTER**

 John Cochrane ▾  EN ▾

Customer Management

0 Customers

Add Customer

Enter the client's Energy Manager serial number and password.

Customer Management » Customer Binding

Customer Binding

Bind existing customer

Serial Number

Device Password

Installer Center 1.6.1.0 © 2017 SOLARWATT GmbH

If the Energy Manager was connected and the user account was created, then the associated account will appear. Click on “bind” to add customer under your account.

Customer Binding

Bind existing customer

Serial Number

ERC04-10000

Device Password

.....

Search

Associated Customer

User Name

John

Email

john@

Bind

If the process was successful, you will see the client's details under Customer Management.

Customer Management

1 Customer



				State ↓	Actions
john@	.com.au	3670	● OK	 	

Add Customer

Once the process has been completed,

- a. You can monitor your client's from the installer login.
- b. Get details of error for all sites.
- c. Add or delete client data
- d. Modify client data
- e. Remotely access client's portal for setup

QUESTIONS AND FEEDBACK